

- (c) Block ailerons into neutral position with aid of clamps.
Remove AN23-22A bolt attaching control wheel to the shaft.
Rotate control wheel on the shaft until it is centered.
Drill 3/16" dia. hole in shaft thru control wheel. Install AN23-22A bolt.
 - (d) Remove aileron clamps.
7. Install or lower deck panel in place. Work front edge of panel under lip of rubber channel at windshield thru entire length. Install screws.
 8. Flight test aircraft and make entry in log book showing compliance with AD 78-20-11.

NOTE: Remove left and right top cable covers at instrument panel prior to removing deck panel in order to avoid damage to cable covers.